



iMac Intel 20" EMC 2105 and 2118 Lower EMI Shield Replacement

Written By: Walter Galan



Step 1 — Lower EMI Shield



- Peel up the lower EMI shield from the rear case.
- ⓘ It is only necessary to peel the shield up from three sides. Leave it attached to the display.
- ⓘ If you happen to rip the EMI shield, use a piece of foil tape to cover the tear.

Step 2



- Tape the EMI shield to the face of the display to keep it out of the way.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-02 07:37:27 AM.